

eways

Voice Mail User Guide

IP COMMUNICATIONS PLATFORM FOR THE SMALL BUSINESS



2 A

Specifications subject to change without notice. Facilities described may or may not be supported by your network. **Opera Flexicom** is the registered trademark of MDS Gateways. DM 851

Table of Contents

7.	Voice Mail User Guide	5
71	Overview	5
7.1	Voico Mail Easturas	6
1.2	Wolcome Message	0
7.2	Paceword Protoction	0
7.2	Divort Calls to a Mailbox	0
7.2	Call Transfer to a Mailbox	
7.2	Break-out of Voice Mail	0
7.2	Call Back	7
7.2	Voicemail Forwarding	7
7.2	Remote Access	7
73	Operating Voice Mail from an Operatone Executive	8
7.0	Divert All Calls to your mailbox using the DIVEPT key	0 8
7.0	Divert All Calls to your mailbox using the Phone menus	0 8
7.0	Divert On No Answer to your mailbox using the Phone menus	۵
7.0	Divert On Rusy to your mailbox using the Phone menus	10
7.3	Retrieve and Play new messages	
7.3	Play a Message	
7.3	Delete a Message	13
7.3	Dial the calling Number	13
7.3	Forward a message	
7.3	Retrieving old messages	
7.3	Record an introductory message	
7.3	Play an Introductory Message	17
7.3	Delete an Introductory Message	17
7.4	Operating Voice mail from an Operatione Standard	
7.4	Divert all calls to your mailbox	
7.4	Divert on No Answer to your mailbox	
7.4	Divert on Busy to your mailbox	
7.4	Retrieve and Play new messages	19
7.4	Retrieve and Play saved messages	20
7.4	Play a Welcome Message	21
7.4	Record a Welcome Message	22
7.4	Delete a Welcome Message	
7.4	Change Diversion Settings	24
7.5	Operating Voice Mail from an Analogue Telephone	
7.5	Voicemail operation from an analogue phone	25
7.5	Retrieving New Messages	25
7.5	Retrieving Old Messages	
7.5	Play a Welcome Message	
7.5	Record a Welcome Message	27
7.5	Delete a Welcome Message	
7.5	Change Diversion Settings	
7.6	Message capacity	30
7.6	System Message Pool	30
7.6	Personal Message Pool	30
7.6	System Storage capacity	30
7.7	Rules for deletion	30
7.7	Auto Delete of Recorded calls/Voicemail Messages based on age	30
7.7	Auto Delete of Recorded Calls, if needed	30
7.7	Auto Delete of Voicemail Messages, if needed	30
7.8	List of Messages on the Voicemail system	

7.8.1	Processing New Messages on the Voicemail system	32
7.8.2	Processing Saved Messages on the Voicemail system	33
7.8.3	Using the mail set-up menu on the Voicemail system	34
7.8.4	Changing diversion settings on the Voicemail system	35
7.8.5	Change Automated Attendant messages via the voice mail menu	36

7. Voice Mail User Guide

7.1 Overview

The integrated voicemail system on the **Opera Flexicom** range of voice and data switches provides a flexible and easy to use solution for recording and retrieving voicemail messages.

The key features of the voicemail system are;

- Three Voice Mail modules are available for the system **Opera Flexicom** systems
 - A two port two hour module which allows two simultaneous connections to Voice Mail for either recording or retrieving messages and two hours storage time (This module is available for the **Opera Flexicom** and **Opera 412em**)
 - A four port four hour module which allows four simultaneous connections and four hours storage time (This module is only available on the **Opera Flexicom**)
 - An applications card that can be loaded with two or more channels (ports) of voice mail and up to thirty hours of storage. Up to eight channels may be assigned for recording and retrieving messages (This module is available for the **Opera Flexicom** and **Opera 412em**). Additional functionality available on this card includes Recording of complete telephone conversations, Music on Hold (in downloadable wav format), Advanced Automated Attendant and IP compression and echo cancellation.
- Voicemail modules on the Opera Flexicom support up to 58 mailboxes while those on the Opera 412em support 22 mailboxes (one for each extension and extension group). Extensions and groups need to be enabled in system programming before they can access Voice Mail.
- The memory time, two or four hours or more, is shared between mailboxes on a first come, first served basis.
- The number of messages per user is programmable [Maximum of 100]
- The message length is programmable [Maximum duration of 3 minutes]
- Once read, a message will be stored for 30 days, after which it will be deleted
- Each mailbox can be password protected for additional level of security
- The system will automatically perform an optimization of the voice card memory at a time that is programmed from the Automatic maintenance time option in browser based programming. During this time the voice card will be disabled for the duration of the process (5 min for 2-hour module, 10 min for 4 hour, approx)

7.2 Voice Mail Features

The voicemail operation on the **Opera Flexicom** systems offers to the user an easy and flexible way of setting up a personalised mailbox and processing the message received.

7.2.1 Welcome Message

Each voicemail user can record a personalised welcome message at his or her extension. This is the message that will be heard by a calling party when the user has diverted his/her extension to voicemail. If a welcome message is not recorded, the system will use the default welcome message.

Default Welcome Message:

- The person you have dialled is unavailable, please leave a message after the tone.

7.2.2 Password Protection

Mailboxes can be password protected to prevent unauthorised access. Password protection needs to be enabled in Browser Based Programming. A PIN code will then have to be entered to gain access to Voice Mail. The PIN code can be entered and changed at the System Phone by entering the **Phone Settings** menu and selecting the **Change Pin Code** option. On analogue extensions, using dialling codes can do this.

Note: - A PIN code must be programmed if the user wishes to remotely access his/her voicemail.

7.2.3 Divert Calls to a Mailbox

The system's **Call Divert** feature is used to divert calls to Voice Mail. There are three types of divert that can be set -

- 1. Divert All Calls
- 2. Divert On Busy
- 3. Divert On No Answer.

The system will allow a user to divert to voicemail even when all of the available memory on the voice card has been used. If the memory of the voice card is full, then the calling party will hear the following message:

"The mailbox of the person you have dialled is currently not available".

7.2.4 Call Transfer to a Mailbox

Calls can be transferred to the mailbox of other extensions. If an enquiry call is made to an extension that is diverted to Voice Mail, the calling extension will hear the welcome message. If, before the message is completed, the calling extension transfers the held call, the welcome message will be restarted and the caller be able to leave a message.

If a System Phone user makes an enquiry call to a extension which has not been diverted to Voice Mail, the call can be transferred to the called extension's mailbox by dialling **#99** during Ringing tone or Busy tone.

7.2.5 Break-out of Voice Mail

If a calling party has been diverted to a user's mailbox, the calling party can break out of the mailbox and ring another extension while hearing the welcome message by dialling a "*" followed by the extension number.

7.2.6 Call Back

The system stores the caller ID information (if this is sent) which enables the user to return the call by using the **Dial** option in Voice Mail.

7.2.7 Voicemail Forwarding

Selecting the Forwarding option enables the message to be forwarded to another voice mailbox on the system.

7.2.8 Remote Access

In order to access the mailbox remotely, the extension user must have programmed a four digit PIN code.

To access Voice Mail remotely:

- Dial into the system using the MSN or line number programmed for the extension that is diverted to Voice mail
- The call will be answered by that extension's voice mailbox
- During the Welcome message, dial # (even if the mailbox unavailable message is received)
- The prompt "Please enter your PIN number" will be heard
- Dial the four digit PIN code

If the correct PIN code is entered then the user will be remotely connected to the voicemail main menu and can access all of the features of the voicemail by dialling the appropriate digits when prompted to do so.

NOTES:

1. The following PIN codes cannot be used to remotely access the voicemail

Any 4 digit PIN code consisting of a **repeated number** (e.g. 1111, 2222, ..) Any 4 digit PIN code consisting of a **consecutive sequence** (e.g. 1234, 5678, ..) Any 4 digit PIN code starting with the digits **19 or 20** (e.g. 1999, 2010,..)

- 2. If NO PIN code has been programmed then dialling # will have no effect.
- 3. If an invalid PIN code is dialled the call will be cleared

7.3 Operating Voice Mail from an Operafone Executive



7.3.2 Divert All Calls to your mailbox u	ising the Phone menus
11:25 Fri 11/01/0	To enable voicemail operation at your
Extension 11	extension the Divert leature must be used.
Menus î↓ Phone B	From the idle display press the Menus mouse key.
Personal Addr Book Common Address Boo ► Call Diversion	With the cursor pointing at Call Diversion press the Select Key.
Select î↓ Exi	The display will then show the 3 types
▶ Divert All Calls Divert No Answer Divert On Busy Select ↑↓ Bac	of divert to select from. With the cursor pointing at Divert All Calls press the Select mouse key.
Divert All Calls ▶ Enabled	In the Divert All Calls menu select the Enabled option.
Disabled ✓ Select ↑↓ Bac	With the Cursor pointing at the Voicemail Option press the select
Divert All Calls ▶ Voicemail	 mouse key The third line of the display will then
Select ↑↓ Bac	k indicate that the Operafone is
11:25 Fri 11/01/0 Extension 11 Divert -> Voicemail Menus ↑↓ Phone B	 diverted to Voicemail and the Divert LED will remain on. All calls to extension 11 will now be diverted to the voice mailbox of extension 11.

Note: To clear diversion simply press the DIVERT key when the LED is on. The phone display will return to the idle condition again. Alternatively the user can dial the **Clear** Divert All Code.

7.3.3 Divert On No Answer to your mailbox using the Phone menus

1 1:25 Fr i. 11/01/04 Extension 1 1 ↑ ↓ м enus Phone Βk Personal Addr Book Address Common Book ► Call Diversion S 1 t elect Exit vert ΑΙΙ Calls D i Divert No Answer ► Divert O n Busy 1 S Back elect D ivert Νo Answer ► Enabled Disabled 1 S elect 1 t Back D ivert No Answer Voicemail ► List Extension S ↑ T Back elect Fri 1:25 11/01/04 1 Extension 1 1 ↑↓ Phone Βk enus м

To enable voicemail operation at your extension the Divert feature must be used.

- From the idle display press the Menus mouse key.
- With the cursor pointing at Call Diversion press the Select Key.
- The display will then show the 3 types of divert to select from. With the cursor pointing at Divert No Answer press the Select mouse key.
- In the Divert No Answer menu select the Enabled option.
- With the Cursor pointing at the Voicemail Option press the select mouse key

Note: The idle display will not indicate when the divert no answer feature has been activated

All calls to extension 11 will ring for the divert no answer timer period after which they will be diverted to the voice mailbox of extension 11.

Note: To clear the Divert On No Answer to the Voicemail, select the **Disabled** option from the Divert No Answer Menu. Alternatively the user can dial the **Clear** Divert On No Answer Code

7.3.4 Divert On Busy to your mailbox using the Phone menus To enable voicemail operation at your 11/01/04 1 1 : 2 5 Fri extension the Divert feature must be used. Extension 1 1 **↑↓ Phone Bk** Menus From the idle display press the Menus mouse key. Addr Personal Book Common Address Book With the cursor pointing at Call Call Diversion elect ↑↓ • ► Diversion press the Select Key. S Exit The display will then show the 3 ΑΙΙ Calls Divert No Answer types of divert to select from. With Divert ► Divert Οn Busy the cursor pointing at Divert On S elect ↑ Back Busy press the Select mouse key. ivert O n Busv D In the Divert On Busy menu select ► Enabled the Enabled option. Disabled 1 1 t S elect Back With the Cursor pointing at the Voicemail Option press the select mouse key D ivert O n Busy ► Voicemail List Extension Note: The idle display will not indicate t S ↑ Back elect when the divert no answer feature has been activated Fri 1:25 11/01/04 1 Extension 1 1 All calls to extension 11 while it is busy ↑↓ will be diverted to extension 11's voice Phone Βk Menus mailbox. Note: To clear the Divert On Busy to the Voicemail, select the Disabled option from the Divert

On Busy Menu shown above. Alternatively the user can dial the **Clear** Divert On Busy Code.

7.3.5 Retrieve and Play new messages New Voice Mail messages are indicated by 1 1:25 Fri 11/01/01 the LED of the **MESSAGE** key flashing and Extension 13 Waiting ↑↓ Pho the number of new messages is shown on Μ essage 3 = Menus Phone Βk the third line of the display of the System Phone. Mailbox Settings • Press the **MESSAGE** key to enter the Enter Pin Code: 1234 Voice Mail menu Accept Exit The system will attempt to access a Voice Mail channel. If all channels are busy, the system will prompt the user to wait. • Enter the PIN code (e.g. 1111) and press the <Accept> key Note: If the mailbox is not password protected, this screen will not be shown. 872979676 3:05√ 0 Any unread messages will be marked with Unknown 1:03√ Extn 14 0 : 21 a $\sqrt{1}$ and the cursor will indicate the last ↑↓ S lect Exit е message received. The CLI (if known) and duration of each message is shown. The example shows two unread messages and a read message from Extension 14. Use the $\uparrow \downarrow$ keys to scroll through the • list of messages Play Press the <Select> key when the • Delete required message is reached Dial ↑ ↓ Select Back There are four options available Play _ Delete **Dial** calling number Forward

7.3.6	Play a Message	
► P D D S e	lay elete ial lect î↓ Back	As shown on the display, with the cursor alongside the Play option – • Press the <select< b="">> key</select<>
1 0 0 8 0 0 P a	: 0 0 Mon 2 4 / 0 6 / 0 2 7 2 9 7 9 6 7 6 : 0 0 : 4 5 u s e B a c k	If the handset is on-hook, handsfree mode will be activated and the selected message will be played. (The handset can be lifted at any time during the message). The length of the message is shown and counts down while it is being played.
1 0 0 8 0 0 R e	: 0 0 Mon 2 4 / 0 6 / 0 2 7 2 9 7 9 6 7 6 : 0 0 : 4 5 s ume Back	 To pause a message - Press the <Pause> key (the function of the key changes to <Resume>) To resume a message - Press the <Resume> key
1 0 0 8 0 0 D e	: 0 0 M o n 2 4 / 0 6 / 0 2 7 2 9 7 9 6 7 6	 Press the <back> key and re-select the <play> option</play></back> To Delete the message - Press the <delete> key</delete> or to return to the message options - Press the <back> key</back>



7.3.8 Dial the	calling Number	
► 0 8 7 2 9 7	9676 3.05	The Dial option enables the user to call back
Unknow Extn 1	$\begin{array}{cccccccccccccccccccccccccccccccccccc$	mail.
Select	I¥ Exit	 Press the <Select> key when the cursor is alongside the calling party ID.
Play Delete		 Press the <select> key when the cursor is alongside the Dial Option</select>
▶ Dial Select	î↓ Back	The System Phone will seize a line and dial the CLI number stored with the message.
		If there is no CLI information recorded with the message, the Dial option will have no effect.

7.3.9 Forward a message	
▶ 0 8 7 2 9 7 9 6 7 6 Unknown Extn 1 4 Select ↑↓ Exit	 The Forward option enables the user to forward a voicemail message to the mailbox of another extension. Use the 1↓ keys to scroll through the list of messages and press the <select> key</select>
Delete Dial ÞForward Select î↓ Back	 With the cursor alongside the Forward option, press the <select> key</select>
► Extn 11 Extn 12 Extn 13 Select ↑↓ Back	 A list of extensions with voicemail will then be displayed. Use the ↑↓ keys to scroll to the desired extension Press the <select> key when the cursor is alongside the extension that you wish to forward the selected message to.</select> The introductory message of that extension's mailbox will be heard. If required, the user can append an additional message to the forwarded message. Note: If the user clears down before the introductory message is completed, the message will not be forwarded.

7.3.10 Retrieving old messages To listen to Voice Mail messages when there 10:00 Fri 03.11.02 are no new messages being indicated at the Extension 1 3 System Phone, i.e. the **MESSAGE** key LED is †↓ Phone not flashing, you can simply press the Menus Βk MESSAGE key or use the mouse keys as follows -Personal Addr Book • Press the <**Menus**> key Call Diversion Use the $\uparrow \downarrow$ keys to scroll through the • ▶ Mailbox S е ttings list of options ↑ Select T Back When the cursor is alongside the Mailbox Settings option, press the Mailbox Settings <Select> kev Enter Pin Code: 1234 Enter the PIN code . Press the <**Accept**> key Accept Exit If the mailbox is not password protected, the display opposite will not appear. ▶ Message List Use the $\uparrow \downarrow$ keys to scroll through the • Setup Voice Mail list of options When the cursor is alongside the ↑↓ Select Back Message List option, press the <Select> key 3:05 • 0 8 7 2 9 7 9 6 7 6 Unknown 1:03 Messages can now be played, deleted, Extn 0:21 14 ↑↓ Select Exit forwarded or dialled as for new messages (see above). Mailbox Empty If all messages are deleted then, Mailbox Empty will be displayed. Back Press the **<Back>** key to return to the • idle screen

7.3.11 Record an introductory message						
10:00 Fri 03.11.02 Extension 13	Simply press the MESSAGE key or use the mouse keys as follows –					
Menus î↓ Phone Bk	• Press the < Menus > key					
Personal Addr Book	 Use the ↑↓ keys to scroll through the list of options 					
Call Diversion	When the cursor is alongside the					
▶Mailbox Settings Select ↑↓ Back	Mailbox Settings option, press the <select> key</select>					
	Enter the PIN code					
Mailbox Settings Enter Pin Code: 1234	Press the < Accept > key					
Accort Exit	If the mailbox is not password protected, the					
	user will not be requested to enter a PIN code.					
Message List ▶Setup Voice Mail	 Use the ↑↓ keys to scroll through the list of 					
	options When the cursor is alongside the Setup 					
Select î↓ Back	Voice Mail option, press the Select > key					
Play	 Use the ↑↓ keys to scroll through the list of options 					
PRecord Delete	 When the cursor is alongside the Record 					
Select î↓ Back	option, press the < Select > key					
	If this is the first time an introductory message					
LIFT HANDSET	is recorded, the Play and Delete options are not shown.					
	Lift the handset as prompted					
	Note: It is not possible to record messages in					
00:00:00	handstree mode.					
Pacard Back	• Press the < Record > key					
	 Press the <stop> key when the message is complete. The message is</stop> 					
Introductory Message	automatically saved					
00:00:50	The record time is shown as the message is					
Stop Back	being recorded.					
	If the < Back > key is pressed, the message will					
00:00:01	not be saved and the display will return to the					
Replay Back	Setup voice mail menu.					
	To listen to the recorded message -					
Introductory Message 00:00:20	• Press the < Replay > key					
	If the message is correct -					
Accept Reject	will return to the Setup Voice Mail menu					
Play ▶ Docord	To re-record the message -					
Delete	Press the < Reject > key. The message					
Select î↓ Back	will be deleted and the display will return					
	to the Setup voice wait menu					

7.3.12 Play an Introductory Message

Ι	n	t	r	ο	d	u	С	t	ο	r	y	М	е	s	s	а	g	е
0	0	:	0	0	:	1	4											
															_			
P	а	u	S	е											в	а	С	κ
Ι	n	t	r	ο	d	u	С	t	0	r	У	Μ	е	s	s	а	g	е
0	0	:	0	0	:	1	4											
															_			
ĸ	е	S	u	m	е										в	а	С	K
Ι	n	t	r	ο	d	u	С	t	Ο	r	У	Μ	е	s	s	а	g	е
0	0	:	0	0	:	1	4											
R	е	p	T	а	v										В	а	С	k
					-												-	

Enter the **Setup Voice Mail** menu as described in the previous section (To Record an Introductory Message) and select the **Play** option.

If the handset is on-hook, handsfree mode will be activated and the introductory message will be played. (The handset can be lifted at any time during the message). The length of the message is shown and counts down while it is being played.

To pause a message -

- Press the <**Pause**> key (the function of the key changes to <**Resume**>)
- To resume the message -
- Press the **<Resume>** key

When the message has finished, to replay-

• Press the <**Replay**> key

or to return to the message options shown on the **Setup Voice Mail** menu Press the **<Back**> key

7.3.13 Delete an Introductory Message						
	Enter the Satur Voice Mail menu as described					
Introductory Message Deleted Back	in the previous section (To Record an Introductory Message) and select the Delete option.					
▶ Record	The message is deleted.					
Select î↓ Back	The display will prompt the user to record a new introductory message.					
	 To record a message - Press the <Select> key 					
	To exit - • Press the < Back > key					

7.4 Operating Voice mail from an Operatione Standard

7.4.1 Divert all calls to your mailbox				
Extension 18	To Divert All Calls to the voicemail simply dial the Divert All Calls code followed by the voicemail code: e.g.			
▶ Voicemail	* 2 1 * * 99 #			
	The display will then indicate that all calls will be diverted to the voicemail.			
Note: To Clear Divert All Calls to the voicemail simply dial the Clear Divert All Calls code (# 21#) and the display will return to the idle condition again.				

7.4.2 Divert on No Answer to your mailbox E x t e n s i o n 1 8 To Divert On No Answer to the voicemail simply dial the Divert On No Answer code followed by the voicemail code: e.g. E x t e n s i o n 1 8 e.g. * 6 1 ** 99 # The display will NOT indicate that Unanswered Calls will be diverted to the voicemail. Note: To Clear Divert On No Answer to the Voicemail simply dial the Clear Divert On No Answer code (# 61#).

7.4.3 Divert on Busy to your mailbox					
Extension 18	To Divert On Busy to the voicemail simply dial the Divert On Busy code followed by the voicemail code.				
Extension 18	e.g. *67**99#				
	The display will NOT indicate that any Calls received in the Busy state will be diverted to the voicemail.				
Note: To Clear Divert On Busy to the voicemail simply dial the Clear Divert On Busy code (# 67#).					

7.4.4 Retrieve and Play new messages

1 New Message

Voicemail

New voicemail message are indicated by the LED of the message key (\boxtimes) flashing and the number of new messages being displayed on the phone display.

To listen to the new message:

• Press the message key (\boxtimes)

The display will then show that the user is in voicemail and the operatione standard will be switched into handsfree mode. If the extension is password protected, the following prompt will be heard -

"Please enter your PIN number",

the user must enter the PIN number using the telephone keypad.

Once the correct pin has been entered, the following introductory message will be heard -

"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"

To listen to the first new message the user must Dial 1.

If there are no new messages, the prompt "You have no new messages" will be heard, followed by the introductory message again.

7.4.5 Retrieve and Play saved messages				
Voicemail	Saved voicemail messages are not indicated from the operafone Idle display. To listen to a saved message: • Dial the voicemail code			
The display will then show that the user is in	voicemail.			
If the extension is password protected, the following prompt will be heard – <i>"Please enter your PIN number"</i> , the user must enter the PIN number using the telephone keypad.				
Once the correct pin has been entered, the following introductory message will be heard $$ -				
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"				
To listen to the first saved message the user must Dial 2.				
If there are no saved messages, the prompt "You have no saved messages" will be heard, followed by the introductory message again.				

7.4.6 Play a Welcome Message		
Voicemail To play the current welcome mes user must - • Dial the voicemail code	sage the	
The display will then show that the user is in voicemail.		
If the extension is password protected, the following prompt will be heard – <i>"Please enter your PIN number"</i> ,		
the user must enter the PIN number using the telephone keypad.		
Once the correct pin has been entered, the following introductory message will be heard -		
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"		
To enter the mail setup menu the user must Dial 3.		
The following Mail Setup message will then be heard:		
"To play the current welcome message - dial 1 To record a new welcome message - dial 2 To delete the current welcome message - dial 3 To return to the previous menu - press *"		
To play the current welcome message the user must Dial 1.		
If a personalised message has not been previously recorded, the default mess " <i>The person you have dialled is unavailable.</i> Please leave a message after the will be heard.	age etone"	

7.4.7 Record a Welcome Messag	je
Voicemail	must -
	• Dial the voicemail code
The display will then show that the user is	in voicemail.
If the extension is password protected, th "Please enter your PIN number",	e following prompt will be heard –
the user must enter the PIN number using	the telephone keypad.
Once the correct pin has been entered, the	e following introductory message will be heard -
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4	1"
To enter the mail setup menu the user mus	st Dial 3.
The following Mail Setup message will the	en be heard:
"To play the current welcome mess To record a new welcome messag To delete the current welcome me To return to the previous menu - p	age - dial 1 1e - dial 2 ssage - dial 3 rress *"
To record a new welcome message the us	ser must Dial 2 .
The user will then be prompted with the fol	lowing message:
"Start recording the new message after	the tone and dial # to end the recording"
The user can start recording the message user then dials # and the following message	after hearing the tone. To end the message the ge will be heard:
"Message recorded"	
The user will then be returned to the Voice	mail setup message.

7.4.8 Delete a Welcome Message	
Voicemail To use	delete the current welcome message the er must -
	Dial the voicemail code
The display will then show that the user is in voice	mail.
If the extension is password protected, the following prompt will be heard – "Please enter your PIN number",	
the user must enter the PIN number using the tele	phone keypad.
Once the correct pin has been entered, the following introductory message will be heard $$ -	
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"	
To enter the mail setup menu the user must Dial 3.	
The following Mail Setup message will then be heard:	
"To play the current welcome message - di To record a new welcome message - dial To delete the current welcome message - To return to the previous menu - press *"	al 1 2 dial 3
To delete the current welcome message the user must Dial 3.	
The user will then hear the following message:	
"Message Deleted"	
The user will then be returned to the Voicemail se	tup message.

7.4.9 Change Diversion Settings	
Voicemail	To change the diversion settings the user must -
	• Dial the voicemail code
The display will then show that the user is in ve	picemail.
If the extension is password protected, the fo "Please enter your PIN number",	llowing prompt will be heard –
the user must enter the PIN number using the	telephone keypad.
Once the correct pin has been entered, the following	lowing introductory message will be heard -
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"	
To change diversion settings user must Dial 4	
The following Diversion Menu will then be heard:	
"To clear diversion dial 1 , to divert to your Voice Mail dial 2 , to divert to the number you called from d to divert to a new number dial 4 followed to return to the previous menu press *."	dial 3 , d by the new number and then # ,
To Clear Diversion the user must Dial 1 . This will then clear the Divert All Calls to voice	mail.
To Divert to Voicemail the user must Dial 2 . This will then set Divert All calls to voicemail.	
To Divert to the Calling party number the us This will divert all calls for that extension to the Mobile number, Home number, etc The line	er must Dial 3. e number that the user is calling from e.g. needs to have CLI functioning for this to work.
To Divert to a New Number the user must Di This will divert all calls for that extension to the	al 4 followed by the New Number and then #. e new number.
To return to the previous menu the user mus	st Dial #.

7.5 Operating Voice Mail from an Analogue Telephone

Voicemail on the **Opera Flexicom** systems is also accessible from analogue phones.

7.5.1 Voicemail operation from an analogue phone

Operating Voice Mail from an analogue telephone can be done simply by dialling a code to access voice mail and following the voice prompts.

- ISDN telephones connected to an internal S-Bus operate in the same way as analogue telephones.
- If password protection has been enabled for an extension but the user has not programmed the PIN code, all inputs will be regarded as invalid.
- If there are no Voice Mail channels available when ***99** is dialled, a proceeding tone is heard and the user will be placed in a queue.
- If Voice Mail has been disabled for the extension, the user will receive **busy** Tone.

7.5.2 Retrieving New Messages

- Lift the handset new messages will be indicated by 'interrupted' Dial tone
- To enter the voicemail menu, dial *99
- If the extension is password protected, at the prompt "Please enter your PIN number", enter the PIN number using the telephone keypad

Note: If an incorrect PIN number is entered, busy tone will be heard.

Once the correct pin has been entered, the following introductory message will be heard -

"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"

To listen to the first new message the user must **Dial 1**.

If there are no new messages, the prompt "You have no new messages" will be heard, followed by the introductory message again.

7.5.3 Retrieving Old Messages

- Lift the handset
- To listen to a saved message, dial *99
- If the extension is password protected, at the prompt "Please enter your PIN number", enter the PIN number using the telephone keypad

Note: If an incorrect PIN number is entered, busy tone will be heard.

Once the correct pin has been entered, the following introductory message will be heard -

"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"

To listen to the first saved message the user must Dial 2.

If there are no saved messages, the prompt "You have no saved messages" will be heard, followed by the introductory message again.

7.5.4 Play a Welcome Message

- Lift the handset
- Dial *99
- If the extension is password protected, at the prompt "Please enter your PIN number", enter the PIN number using the telephone keypad

Note: If an incorrect PIN number is entered, busy tone will be heard.

Once the correct pin has been entered, the following Welcome message will be heard -

"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"

To enter the Mail Setup menu the user must **Dial 3**.

The following Mail Setup message will then be heard:

"To play the current welcome message - dial 1 To record a new welcome message - dial 2 To delete the current welcome message - dial 3 To return to the previous menu - press *"

To play the current welcome message the user must Dial 1.

If a personalised message has **not** been previously recorded, the default message "*The person you have dialled is unavailable. Please leave a message after the tone*" will be heard.

7.5.5 Record a Welcome Message
 Lift the handset Dial *99 If the extension is password protected, at the prompt <i>"Please enter your PIN number"</i>, enter the PIN number using the telephone keypad
Note: If an incorrect PIN number is entered, busy tone will be heard.
Once the correct pin has been entered, the following Welcome message will be heard -
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"
To enter the Mail Setup menu the user must Dial 3 .
The following Mail Setup message will then be heard:
"To play the current welcome message - dial 1 To record a new welcome message - dial 2 To delete the current welcome message - dial 3 To return to the previous menu - press [★] "
To record the welcome message the user must Dial 2.
The user will then be prompted with the following message:
"Start recording the new message after the tone and dial # to end the recording"
The user can start recording the message after hearing the tone. To end the message the user then dials # and the following message will be heard:
"Message recorded"
The user will then be returned to the Voicemail setup message.

7.5.6 Delete a Welcome Message
 Lift the handset Dial *99 If the extension is password protected, at the prompt <i>"Please enter your PIN number"</i>, enter the PIN number using the telephone keypad
Note: If an incorrect PIN number is entered, busy tone will be heard.
Once the correct pin has been entered, the following Welcome message will be heard -
"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"
To enter the Mail Setup menu the user must Dial 3 .
The following Mail Setup message will then be heard:
"To play the current welcome message - dial 1 To record a new welcome message - dial 2 To delete the current welcome message - dial 3 To return to the previous menu - press *"
To delete the welcome message the user must Dial 3 .
The user will then hear the following message:
"Message Deleted"
The user will then be returned to the Voicemail setup message.

7.5.7 Change Diversion Settings

- Lift the handset
- Dial *99
- If the extension is password protected, at the prompt "Please enter your PIN number", enter the PIN number using the telephone keypad

Note: If an incorrect PIN number is entered, busy tone will be heard.

Once the correct pin has been entered, the following introductory message will be heard -

"Welcome to voice mail – For new messages – dial 1 For saved messages – dial 2 To enter Mail Setup menu – dial 3 To change diversion settings – dial 4"

To change diversion settings user must Dial 4.

The following **Diversion Menu** will then be heard:

"To clear diversion **dial 1**, to divert to your Voice Mail **dial 2**, to divert to the number you called from **dial 3**, to divert to a new number **dial 4** followed by the new number and then #, to return to the previous menu **press *.**"

To **Clear** Diversion the user must **Dial 1**. This will then clear the Divert All Calls to voicemail.

To **Divert to Voicemail** the user must **Dial 2**. This will then set Divert All calls to voicemail.

To **Divert to the Calling party number** the user must **Dial 3**. This will divert all calls for that extension to the number that the user is calling from. - e.g. Mobile number, Home number, etc... The line needs to have CLI functioning for this to work.

To **Divert to a New Number** the user must **Dial 4** followed by the **New Number and then #.** This will divert all calls for that extension to the **new** number.

To return to the previous menu the user must Dial #.

7.6 Message capacity

7.6.1 System Message Pool

The system has an SPG database that can hold 1,000 messages. Each Recorded call or Voicemail message takes one entry in the database.

7.6.2 Personal Message Pool

Each Extension or Group has one personal message pool for Recorded calls (Minimum 10 and Maximum 100 with a default of 20) and another pool for Voicemail messages (Minimum 10 and Maximum 100 with a default of 20).

7.6.3 System Storage capacity

The system has from 20 Minutes to 20 Hours Memory capacity for storing Recorded calls and Voicemail messages.

7.7 Rules for deletion

Messages are deleted either based on age or based on having reached the maximum number of personal Recorded calls (default pool size 20) or on having reaching the maximum number of personal Voicemail messages (default pool size 20).

Messages will not be deleted because the storage capacity is reached.

7.7.1 Auto Delete of Recorded calls/Voicemail Messages based on age When a message is first recorded its age is set to 0. Each night at midnight, if the message is marked as *Read or Email Forwarded*, its age is incremented by 1. On reaching 30, the message is deleted.

7.7.2 Auto Delete of Recorded Calls, if needed

If the system needs to record a call, and if there's sufficient storage capacity available, it will follow these steps.

Check that there is a free entry in the System Message Pool and a free entry in the Personal Message Pool. If there is, then record the call. If not, then try to delete a message in the following order and then try again.

- Delete Oldest *Read* Recorded call.
- Delete Oldest Unread but Email Forwarded Recorded call.
- If it's an Analogue or Single line display Extension then delete Oldest *Unread* Recorded call.

7.7.3 Auto Delete of Voicemail Messages, if needed

There is no automatic deletion of Voicemail messages. If the system needs to record a Voicemail message, it proceeds as follows.

Check that there is a free entry in the System Message Pool and a free entry in the Personal Message Pool. If there is, then record the message. If not then Play the "This mail box is full" massage and clear down.

7.8 List of Messages on the Voicemail system

The list below details the messages that are contained by default on the voicemail module. Only one of these messages (Message 6 – Welcome message) is recordable by the user. Messages 1, 2, 11 & 16 are automatically repeated up to a maximum of 3 times if a digit is not entered.

Message Name	Message Contents
1. Main Menu	Welcome to Voice Mail, for new messages dial 1, for saved messages dial 2, to enter the Mail Set-Up menu dial 3 or to change diversion settings dial 4.
2. Setup Menu	To play the current welcome message dial 1, to record a new welcome message dial 2, to delete the current welcome message dial 3 or to return to the previous menu dial *.
3. Record	Start recording the new message after the tone and dial # to end recording.
4. Record Complete	Message recorded.
5. Delete	Message deleted.
6. Welcome [Recordable]	The person you have dialled is unavailable. Please leave a message after the tone.
7. New Message	You have new messages.
8. No New Message	You have no new messages.
9. No Saved Message	You have no saved messages.
10. No More Messages	You have no more messages.
11. End of Message	To replay the last message dial 1 , to delete the message dial 2 , to play the next message dial 3 , to forward the message dial 4 followed by an extension number, to return the call to this person dial 5 , to return to the previous menu press *.
12. Enter PIN	Please enter your PIN number.
13. BEEP	"BEEP"
14. Divert Call	Your call is being diverted, please hold.
15. Mailbox Busy	The mailbox of the person you have dialled is currently not available.
16. Diversion Menu	To clear diversion dial 1 , to divert to your Voice Mail dial 2 , to divert to the number you called from dial 3 , to divert to a new number dial 4 followed by the new number and then or to return to the previous menu dial *.
17. Diversion Changed	Call Diversion has been changed.
18. Diversion Not Changed	Call Diversion has not been changed.

7.8.1 Processing New Messages on the Voicemail system

The flow chart below shows the sequence of messages heard by the user on processing New messages from the voicemail menu. Digits dialled while listening to a menu are represented by circled numbers.



7.8.2 Processing Saved Messages on the Voicemail system

The flow chart below shows the sequence of messages heard by the user on processing New messages from the voicemail menu. Digits dialled while listening to a menu are represented by circled numbers.



7.8.3 Using the mail set-up menu on the Voicemail system

The flow chart below shows the sequence of messages heard by the user when using the voice mail set-up menu. Digits dialled while listening to a menu are represented by circled numbers.



7.8.4 Changing diversion settings on the Voicemail system

The flow chart below shows the sequence of messages heard by the user when changing call diversion settings on the voicemail system. Digits dialled while listening to a menu are represented by circled numbers.



7.8.5 Change Automated Attendant messages via the voice mail menu

The flow chart below shows the sequence to be followed by a user, with Operator level of access, to alter the Automated Attendant messages. This can even be done remotely. Access the Voicemail Main Menu, for example by dialing #, followed by your PIN, while listening to the welcome message. Then instead of following any of the standard 1 to 4 prompts, dial 6 followed by the index number of the AA message to be recorded, unprompted.

Circled numbers represent digits dialed at the various stages.

